



MSAA112E

\$39

Product Images



Description

Diffuser kit for diamond image capture with Dino-Lite Edge Series Models. Includes 2 diffusers at different heights designed for viewing Diamonds. (Dino-Lite not included) - Insert by gently placing diffuser inside cap. Ensure diffuser is positioned straight to avoid damaging LEDs. - If the diffuser is too loose, place a 1mm or 1.5mm rubber spacer (included) over the recessed area around the edge of the diffuser. - To remove from AM models, hold clear plastic cap down with one hand, while gently twisting and pulling diffuser with the other hand.

Additional Information

Warranty Period	1 year
Manufactured in	China
Service & Support	U.S. (www.dinolite.us) English & Spanish
Regulatory Approval	ROHS
Dimensions	29mm x 36mm / 1.14" x 1.41"
Weight	6g / 0.02 oz
Material	Plastic
Compatible with	Dino-Lite Edge Series
Package Includes	Diffuser, Instruction Guide
Package Dimensions	7.6cm(L) x 5.1cm(W) x 3.2(H) / 2.1" x 2" x 1.26"
Package Weight	20g / 0.04 lb

