



# MSA2G

\$49

## Product Images



## Description

Designed for Dino-Lite: The MSA2G is a lightweight portable stabilizing stand meant to assist with inspecting hard to reach surfaces such as helicopter blades. The three legged, sturdy metal design keeps the Dino-Lite orthogonal to the surface. It also prevents the

Dino-Lite from accidentally falling over when not in use. Each leg also has a special non-slip rubber pad to protect the surface being inspected and prevent the Dino-Lite from accidentally slipping out of position. The package includes a rubber band which should be placed on the Dino-Lite body before installing the MSA2G. This will provide a stable, secure connection between the microscope and stand. Then, use the three thumb screws to lock the Dino-Lite in the center of the MSA2G.

## Additional Information

---

Warranty Period	1 year
Manufactured in	China
Service & Support	U.S. ( <a href="http://www.dinolite.us">www.dinolite.us</a> ) English & Spanish
Regulatory Approval	ROHS
Dimensions	8.6cm x 9.3cm x 3.5cm
Weight	2.5oz
Compatible with	All Dino-Lite Handheld Microscopes
Package Includes	Metal stand, three thumb screws, plastic connection ring, and rubber band

